




Face & Body Rejuvenator



Introduction

The Medescan Face & Body Rejuvenator is a waterproof unit ideal for use in the bathroom. Your Medescan Rejuvenator comes complete with 4 interchangeable attachments: Body Cleaning Brush, Facial Brush, Facial Sponge and a Pumice Stone.




Inserting the batteries

Please make sure that your hands are dry when inserting the batteries.

The Medescan Rejuvenator uses 4 x AA batteries. For an extended running time, we recommend the use of Alkaline batteries.

- 1. Use one hand to hold the Rejuvenator and the other hand to hold the battery cap with the thumb at the "Open" mark position.*
- 2. While pressing on the "Open" mark, pull the cap off (Refer to the image below).*
- 3. Insert 4 x AA batteries ensuring the correct alignment with +/- markings on the Medescan Rejuvenator*
- 4. Replace the battery cap ensuring a secure fit.*



Using the Face & Body Rejuvenator

Caution: Do not use the Medescan Face and Body Rejuvenator on broken skin or areas with rash, severe acne or any other skin ailments. This may worsen your condition

Install the desired attachment and press the On/Off button to switch on the Medescan Rejuvenator.

Body Brush:

is suitable for hand and body application. Simply apply your favourite cleanser to the surface of the brush and gently move across your skin in a circular motion.



Pumice Stone

Caution: Abrasive attachment.

Please soak your feet in warm water then wipe dry. Apply the pumice stone to the heel and move in a circular motion. The rotating pumice stone will remove hardened skin and dead cells. This attachment may also be used on elbows.



Face Sponge:

The cosmetic facial sponge gently massages activating skin activity and elasticity. Treatment with the facial sponge also greatly increases the absorption and penetration of beauty products and creams.

Gently move the sponge across your face in circular motion



Face Brush

The bristles of the face brush are specifically designed for the soft and tender skin of the face. For best results, apply your favourite cleanser to the brush and gently move across your face in a circular motion.

Please ensure the brush remains flat against the skin and not on an angle to avoid any irritation



Cleaning & Maintenance

Caution: Do not use any alcohol, acetone or abrasive cleaning agents to clean your Medescan Face & Body Rejuvenator.

- *Rinse applicators with warm tap water*
- *Thoroughly rinse brushes and brush bristles.*
- *Note: you can restore the bristles to their original shape by rinsing in warm water*
- *Use a damp cloth to wipe clean any residue on main Rejuvenator body*
- *Air dry all parts*
- *Store the unit in its original box ready for next useage.*
- *Remove the batteries if storing for an extended period of time.*

Replacing the attachments

It is recommended to replace the brushes and sponge every 2 - 3 months of use.

Replace the brushes if bristles cannot be restored to original shape under hot water.

Worn and deformed brushes are ineffective in removing impurities and may cause skin irritation.

Replacement attachments available from your original place of purchase.